



Arial® Wireless Repeater

The Arial wireless repeater increases the range of your Arial system without expensive hardwiring. The wireless repeater picks up radio signals from call transmitters and other repeaters, then amplifies and retransmits the signals to the wireless receiver.

An AC transformer (included) plugs into any standard electrical outlet to power the wall mounted wireless repeater. In the event of a power outage, the wireless repeater can be backed up by an optional interior 12V battery, which is recharged by a battery charging circuit. The weatherproof accessory kit allows you to mount repeaters outdoors, enabling coverage of courtyards and other campus areas. The repeater has a low battery alert to indicate when the battery should be replaced.

Standard Features

- ▲ **Receives signals from:**
- ▲ **Portable pendants**
- ▲ **Fixed wall transmitters**
- ▲ **Smoke detectors**
- ▲ **PIR sensors**
- ▲ **All Arial 900 MHz wireless devices**

Optional Accessory Kit Includes:

- ▲ **12 volt battery backup**
- ▲ **Weatherproof housing**
- ▲ **Easy installation**

Benefits

- ▲ **Increases range of your system**
- ▲ **Fully supervised (self testing)**
- ▲ **Unlimited repeaters in any facility**

Specifications

- ▲ **Power: 14v AC wall transformer**
- ▲ **Frequency: 900 MHz spread spectrum**
- ▲ **Bandwidth: 100KHz**
- ▲ **Dimensions: 6.3" x 3.6" x 1.1"**
- ▲ **Weight: 6.9 oz.**

STANLEY®
Healthcare Solutions
Toll-Free: 800-824-4494

Office: 402-475-4002

Fax: 402-475-4281

www.stanleyhealthcare.com