

STANLEY

AccessPro door automator™ Model 313900

Remote keyfob
with Velcro® strap



STANDARD FEATURES

- ▲ Installs quickly and easily in 2 to 3 hours
- ▲ Powered by a 120V AC plug-in adapter
- ▲ FCC compliant
- ▲ Moves door with less than 40 lbs of force
- ▲ Stops on obstruction
- ▲ Up to 15 remote controls can be programmed to one door
- ▲ Remote controls operate the door up to 30 feet away
- ▲ Remote frequency uses rolling code technology

AccessPro
door automator™

The **AccessPro door automator** promotes resident independence by automating doors to open, close, lock and unlock on command. The lightweight remote keyfob attaches to a walker, wheelchair, scooter or cane using a Velcro strap. Up to 15 remote controls can be programmed to operate a single door. A simple push of the button activates the AccessPro from up to 30 feet away. The automator will slowly move the door using less than 40 lbs of force, and automatically stops if there is an obstruction. Residents can safely walk through the doorway without having to pull and maneuver the heavy door.

The AccessPro door automator can be disabled simply by pulling the “unlatching arm.” Room keys can also be used to lock and unlock the door. In the event of a fire or power outage, the spring hinge assembly automatically releases, allowing manual passage through the door.

Incorporating the AccessPro into your facility can help:

- Improve your resident retention
- Create incremental revenue
- Increase staff productivity
- Differentiate your facility from other centers
- Improve safety
- Enhance your residents' quality of life

Call us toll free at **800-824-4478** or visit **www.stanleyhealthcare.com**